

Connect Page - Microsoft Internet Explorer

Адрес: http://f11/cgi-bin/status.cgi

## Connect Page


The connection is down.

Dialling attempt 1: Module reported an error while dialling.

### GPRS status and signal level


Could not talk to SIM card, please check connection

The signal level is given for the strongest station available. If the meter is red, there is no connection. If the GPRS is not logged on to the network this may be due to not having inserted the SIM-card correctly or having bad reception.



### Satellite signal quality

The signal quality level meter shows the quality of your signal. If the meter is red, there is no connection. Yellow represents a possibly intermittent connection and green a stable connection. Once your system is correctly set-up, connection to the satellite will be automatic. You can click the Connect/Disconnect button to manually connect or disconnect the modem link to the ISP.



### Transfer statistics

Device	Received	Sent
Ethernet	109698	315290
Satellite	0	N/A

Здесь мы можем видеть уровень GPRS сигнала

Здесь мы можем видеть уровень сигнала со спутника

Satellite Settings - Microsoft Internet Explorer

Адрес: http://f11/cgi-bin/config.cgi

## Set-up

Online: 0:03:18

Important information about passwords

- Upper and lower case letters in the password are distinct.
- A new password has to be entered twice, to catch mistakes in the input

Здесь мы водим имя пользователя и пароль

Username:

Password:

Password (repeat):

SIM PIN:

Enable use of GSM data:

Phone Number:

GPRS APN:

GPRS auto connect on startup:

Automatic Disconnect when idle after:  minutes

Language:

Country:

Здесь мы ставим флажок GPRS авто подключение. Потом водим точку APN для входа в Интернет через SIM-карту. APN точка для Life:

Advanced Satellite Settings - Microsoft Internet Explorer

Адрес: http://f11/cgi-bin/config\_advanced.cgi

**skysat+**

Connect page  
Set-up  
**Advanced Settings**  
Updates & Support  
Exclusion List  
Network set-up  
Proxy set-up  
Tellitec page

### Advanced Settings

Frequency: 12380000  
Symbol Rate: 27500  
Polarisation: Horizontal  
DiSEqC Setting: DiSEqC Disabled  
PIDs: 262,263  
Multicast PIDs: 262,263

The use of the Tellitec and TellitecCast software is subject to a license agreement with Tellitec Communications byba ([www.tellitec.be](http://www.tellitec.be)). Any use without a valid license agreement is forbidden and will be prosecuted.

Proxy server: sirius.proxy.astra-net.com  
Save Restore

Здесь водятся частоту: 12380000; символную скорость 27500; ставим горизонтальную поляризацию;

Здесь водим Proxy server: sirius.proxy.astra-net.com

В этих двух полях устанавливаем два фильтра 232,263

Местная интрасеть 17:40

Connect Page - Microsoft Internet Explorer

Адрес: http://f11/cgi-bin/status.cgi

**skysat+**

Online: 0:02:53

Connect page  
Set-up  
Advanced Settings  
Updates & Support  
Exclusion List  
Network set-up  
Proxy set-up  
Tellitec page

### Connect Page

The connection is up.  
Disconnect

#### GPRS status and signal level

GPRS module in use

#### Satellite signal quality

The signal quality level meter shows the quality of your signal. If the meter is red, there is no connection. Yellow represents a possibly intermittent connection and green a stable connection. Once your system is correctly set-up, connection to the satellite will be automatic. You can click the Connect/Disconnect button to manually connect or disconnect the modem link to your ISP.

#### Transfer statistics

Device	Received	Sent
Ethernet	81800	157011
Satellite	136968	N/A
Modem	28273	53601

Такие сообщение говорит о том, что мы правильно сделали все настройки GPRS и установили соединение

Шла такого вида говорит об отличном уровне сигнала со спутника

Готово Местная интрасеть 14:23

Network set-up - Microsoft Internet Explorer

Адрес: http://f11/cgi-bin/config\_network.cgi

skysat+

Network set-up

IP address: 192.168.30.1  
Subnet mask: 255.255.255.0  
DHCP server enabled:   
Starting IP address: 192.168.30.20  
Ending IP address: 192.168.30.254  
DVB IP address: 169.254.30.1  
Use specified DNS server:   
DNS IP address: 0.0.0.0  
Second DNS IP address: 0.0.0.0

Save Restore

В этом окне мы можем сделать такие настройки:  
- установка IP адреса устройства;  
- установка DHCP сервера;  
- установку маски;  
- установку DNS

DNS IP 212.2.96.51  
Second DNS IP 212.2.96.52

Proxy setup - Microsoft Internet Explorer

Адрес: http://f11:2517/www/proxyuser.html

skysat+

Proxy setup

Important information about passwords

- Upper and lower case letters in the password are distinct.
- A new password has to be entered twice, to catch mistakes in the input.

Username:   
Password:   
Password (repeat):

Save

Здесь необходимо вести ваш логин, и пароль дважды